


# DARK ADVENTURE DARK ADVENTURE DARK ADVENTURE

# DARK ADVENTURE: SUB HARNESSES

	1 2	COIN 3	RED
	3	3P LEFT	WHITE/RED
	4	3P RIGHT	WHITE/YELLOW
CN3	5	3P UP	WHITE/BLACK
3P	6	3P DOWN	WHITE/BLUE
CONTROLS	7	3P JUMP/START	WHITE/BROWN
(JST)	8	3P ATTACK	WHITE/ORANGE
	9	3P DYNAMITE	WHITE/GRAY
	10		
	11		
	12	COIN COUNTER 3	BLUE
	13		
	14		-
	15	GROUND	BLACK
CN8	1	SPEAKER +	WHITE
SPEAKER	2	SPEAKER -	BLACK
OUTPUT	3	SPEAKER -	BLACK
(JST)	4	SPEAKER +	GRAY

# **DARK ADVENTURE: AC FLOW CHART**

- 1. GREEN/YELLOW
- 2. BLACK
- 3. RED
- 4. BLUE
- 5. BROWN
- 6. RED/BLACK
- 7. BLACK/WHITE
- 8. WHITE
- 9. GREEN
- 10. VIOLET
- 11. ORANGE




# **DIP SWITCH SETTINGS**

#### **DIP SWITCH NO. 1 SETTINGS**

	DII OWITOTI NO. 1 OLI IMAG						
sw	1	2	3	4	COIN	CREDIT	
•	OFF	OFF	OFF	OFF	1	1	
	ON	OFF			1	2	
	OFF	ON			1	3	
	ON	ON			1	4	
	OFF	OFF	ON	OFF	1	5	
	ON	OFF			1	6	
	OFF	ON			1	7	
	ON	ON			2	1	
	OFF	OFF	OFF	ON	2	3	
	ON	OFF			2	5	
	OFF	ON			3	1	
	ON	ON			3	2	
	OFF	OFF	ON	ON	3	4	
	ON	OFF			4	1	
	OFF	ON			4	3	
	ON	ON			INV	ALID	

#### **DIP SWITCH 1**

ON OFF



SW5 through
SW8 are not used.

## **DIP SWITCH NO. 2 SETTINGS**

#### THE NUMBER OF THE PLAYER'S LIFE

	1	2	NUMBER
	OFF	OFF	2
•	ON	OFF	3
	OFF	ON	5
	ON	ON	7

\*The number of players life multiplied by the number of credit makes the number of players life for a play

#### DIFFICULTY OF THE GAME

sw	6	7	DIFFICULTY
	OFF	OFF	EASY
•	ON	OFF	NORMAL
	OFF	ON	DIFFICULT
	ON	ON	VERY DIFFICULT

#### SOUND

sw	8	SOUND
	OFF	OFF
. •	ON	ON

#### **DIP SWITCH 2**

ON OFF

•					•		•
	•	•	•	•		•	
1	2	3	4	5	6	7	8

SW3 through SW5 are not used.

#### **DIP SWITCH NO. 3 SETTINGS**

#### 1. VIDEO SCREEN FLIP

sw	1	FLIP
•	OFF	NORMAL
	ON	UPSIDE DOWN

#### 2. CHANGE OF MODE

SW	3	MODE
•	OFF	GAME MODE
	ON	CHECK MODE

#### **DIP SWITCH 3**

ON OFF




SW2 and SW4 are not used.

#### **SELF TEST**


- A. How to start.
  - 1. Turn on the SW3 of the DIP SW3.
- B. Test Items.
  - 1. Color Conditioning.
  - 2. Control Check.
  - 3. Coin Counter Check.
  - 4. DIP SW SET.
  - 5. Sound Check.
  - 6. Video Screen Flip.

<sup>\*</sup>To change items, push MAP button.

<sup>\*</sup>Push 1P SHOOT (JUMP, START) button to change sound.



# Gold Mech: Service Information CLEANING and CARE of the MECHANISM



The magnet that is fitted to the mechanism, should be kept clean from foreign particles. The magnet can be cleaned by swinging the gate open. (as shown in Fig. 1). Remove metal filings from the magnet by guiding the point of a screwdriver along the edges of the magnet, such that the filings cling to the screwdriver.

The mechanism can be cleaned by immersing in water using a small brush to clean the mechanism. Rinse the mechanism with boiling water and dry with compressed air.

#### Note:

Since the Gold Mech relies on coins passing the magnet at a constant speed, the rejector must be free of dirt and grease which may slow down the coins. Do not lubricate the acceptor with oil as this slows down coins.


If the above procedures are not successful, check for worn, bent or damaged parts and replace where necessary.

#### Coin switch

The coin switch comes in two different spring tensions—identified by the color of the plastic boss at the wire's pivot point.

Red: Light tension—U.S. 25¢


White: Heavy tension—heavy foreign coins



#### Removal of Mechanism


To remove the coin selector: Unscrew the two screws (as shown in Fig. 2)—swing rear of selector body away from the lock-out side and withdraw.

The Gold Mech Acceptors are designed to require a minimum of maintenance and field adjustment. Coins are checked by diameter and thickness, weight, metal content, bounce, and for ferromagnetic coins such as nickel and steel, a rim test is also used.



### The Magnet

Coins that are too thick will fail to pass between the magnet and the backplate of the mechanism; and will be cleared by the magnet wiper when the reject lever is actuated. (Fig. 3)



#### **PARTS LIST**

90-1030-00 Retaining Screw (#6-32" x .250") 91-1036-00 Mounting Stud

91-3001-00 Back Plate 91-3002-00 Reject Lever

91-3003-00 Reject Lever Spring

91-3006-00 Cover Plate

91-3008-00 Anti-Stringing Device

91-3009-00 Gate

91-3011-00 Cradle

91-3013-00 Magnet Holder with Magnet

91-3016-00 Gate Spring

91-3017-00 Gate Pin

91-3019-00 Separator

91-3022-00 Diameter Adjustment

91-3023-00 Locknut-Magnet Holder


91-3024-00 Screw-Magnet Holder

91-3025-00 Screw Separator


91-3026-00 Washer

91-3028-00 Cotter Pin for Anti-Stringing Device

91-3029-00 E-Clip for Cradle



#### **EXPLODED VIEW**



#### **PARTS LIST**

12-4050-01 S-10 Acceptor Body US 25¢ 12-4050-03 S-10 Acceptor Body Canadian 25¢ 20-4177-00 Plastic Cash Box 20-4179-00 Steel Enclosure 22-1400-00 Locking Bar 24-1150-00 Wire Harness 90-1000-00 Keyhook Bezel Screw 90-1001-00 Bezel Screw 90-1002-00 Hinge Screw 90-1003-00 Clamp Screw 90-1007-00 Flat Head Microswitch Mounting Screw 90-1008-00 Panhead Microswitch Mounting Screw

90-1207-00 Nut for Microswitch Mounting Screw 90-1300-00 Keyhook 91-0502-00 Zinc Die Cast Frame 91-0503-00 Lower Door 91-0504-00 Upper Door 91-0505-00 Round Lock and Cam Assembly 91-0506-00 Clamp 91-0515-00 Flat Lock and Cam Assembly 91-0535-00 Flat Lock and Cam Assembly 91-0545-00 Round Lock and Cam Assembly

90-1102-00 Washer for Bezei Screw

91-1103-00 Coin Inlet Lamp Side 91-1104-00 Coin Inlet Cover Side 91-1105-00 Reject Cup Side Plate 91-1106-00 Reject Cup Base Plate 91-1107-00 Microswitch Bracket 91-1108-01 Lockout Flap US 25¢ 91-1109-00 Reject Flap 91-1110-00 Metal Switch Adjuster 91-1111-00 Black Button Bezel 91-1112-00 Black Reject Bezel 91-1113-01 Entry/Reject Button US 25¢ 91-1116-00 Microswitch (Black End Arm) 91-1117-00 Lampholder 91-1118-00 6 Volt Wedge Base Lamp

91-1119-00 Button Spring 91-1120-00 Lockout Spring 91-1122-00 Retaining Screw for Acceptor Body 91-1125-00 Clear Plastic Cover for Microswitch 91-1127-00 Plastic Switch Adjuster 91-1141-00 Base Plate With Pivot and Stud 91-1144-00 6 Volt DC Lockout Coil Assembly 91-1211-00 Zinc Plated Button Bezel 91-1212-00 Zinc Plated Reject Bezel